




DIRECTIONS FOR USE

1. Take your Vollara® Air & Surface Pro XL unit out of the shipping carton and remove all protective materials.

CAUTION: Read manual carefully for proper use and optimal operation.

2. Place your unit in an appropriate location which should be four feet or higher from the ground. **Never set the unit on the floor.** Place in a location away from the HVAC return duct. The rear of the unit requires one inch or more of open area to allow unrestricted airflow.
3. Insert the Power Supply Plug into the power receptacle on the rear of the unit.
4. Insert the AC Plug on the Power Cord into the Power Supply and the other end into a working electrical outlet.
5. The Vollara Air & Surface Pro XL can be turned ON or OFF, and adjusted, using the Control Panel on the front of the unit.
6. Push the **POWER** button once to turn the unit ON.
7. When the unit is powered on, both the (2) ActivePure Cell Assemblies and the Carbon Brushes (ionizer) are operating and will be illuminated on the Control Panel.
8. Push the **FAN+** button four times to reach the highest fan speed (5th level) to initially clear the air in the room. Once the air is cleared, set to the desired fan speed.

CONGRATULATIONS!

You are now set up to receive the benefits of your Vollara Air & Surface Pro XL.

SETTINGS & NOTIFICATIONS

-  **POWER (STAND BY)**
Turns the unit **ON** and **OFF**.
-  **RESET**
Clears the maintenance reminders after performing routine maintenance.
-  **ION**
Illuminates to indicate Carbon Brushes (Ionizer) are operating.
-  **FAN**
Adjusts the 5-speed Fan **UP** and **DOWN**.
-  **IONIZER**
Press to turn Carbon Brushes (Ionizer) **ON** and **OFF**.

A·PURE x2

A·PURE x2 illuminates to indicate that 2 ActivePure Cell Assemblies are operating.

For best results, run your Vollara Air & Surface Pro XL 24/7/365, giving you the benefits of ActivePure® Technology day and night.


For maintenance and cleaning instructions, refer to the owner's manual.



READ MANUAL CAREFULLY FOR PROPER
USE AND OPTIMAL OPERATION

Vollara.com/manuals





DIRECTIONS D'UTILISATION

- Sortir l'appareil Vollara Air & Surface Pro XL de son carton d'expédition et retirer tous les matériaux d'emballage.

ATTENTION: Lire attentivement le manuel afin d'utiliser correctement l'appareil et d'assurer son fonctionnement optimal.

- Placer l'appareil à son emplacement définitif, qui doit se trouver à quatre pieds ou plus au-dessus du sol. **Ne le relentez jamais sur le sol.** Placer dans un endroit éloigné du conduit de retour du CVC. Laisser un dégagement à l'arrière de l'appareil, au moins un pouce, pour permettre à l'air de circuler librement.
- Insérer la fiche d'alimentation dans la prise prévue à cet effet à l'arrière de l'appareil.
- Insérez la prise AC sur le cordon d'alimentation dans l'alimentation et l'autre extrémité dans une prise électrique fonctionnelle.
- Le Vollara Air & Surface Pro XL peut être **MARCHÉ** ou **ARRÊT**, et ajusté, à l'aide du panneau de commande à l'avant de l'unité.
- Appuyer une fois sur le bouton **MARCHÉ/ARRÊT** pour mettre l'appareil sous tension.
- Une fois l'unité sous tension, les (2) éléments de la cellule ActivePure et les Brosses à carbone (ioniseur) fonctionnent et seront éclairées sur le panneau de commande.
- Appuyer quatre fois sur le bouton **FAN+** pour atteindre la vitesse la plus élevée (5e niveau) pour dégager initialement l'air dans la pièce. Une fois l'air dégagé, réglez à la vitesse souhaitée du ventilateur.

ÉTATS ET NOTIFICATIONS

- POWER (TENEZ-VOUS PRÊT)**
Allume et désactive l'unité.
- RESET**
Ce bouton de réinitialisation efface les rappels d'entretien une fois l'entretien de routine effectué.
- ION**
L'ion s'éclaire pour indiquer les brosses en carbone (Ioniser) sont en activité.
- FAN**
Ajuste les 5 vitesses Fan HAUT et EN BAS.
- IONIZER**
Appuyez pour activer et éteindre les pinceaux en carbone (Ioniser).

A·PURE x2

A·PURE x2 Illumines pour indiquer que les deux éléments de la cellule ActivePure fonctionnent.

Pour les meilleurs résultats, faites fonctionner votre Vollara Air & Surface Pro XL 24/7, offrant les avantages d'Technologie ActivePure® jour et nuit.

Pour les instructions d'entretien et de nettoyage, veuillez vous reporter au manuel d'utilisation.

FÉLICITATIONS!

Vous êtes maintenant prête à bénéficier des avantages de votre appareil Vollara Air & Surface Pro XL.



LIRE ATTENTIVEMENT LE MANUEL AFIN D'UTILISER CORRECTEMENT L'APPAREIL ET D'ASSURER SON FONCTIONNEMENT OPTIMAL

[Vollara.com/manuals](https://vollara.com/manuals)

