

ACTIVECLEAN PORT FOR LAUNDYPURE 2.0

INSTALLATION INSTRUCTIONS


The ActiveClean Port for the LaundryPure 2.0 includes the adapter hardware with attached tubing and a Velcro® strap to conveniently store the tubing. (A) Installation is quick and easy. To use the ActiveClean Port, hold a container under the tube and simply turn the valve handle clockwise. To turn off the ActiveClean Port, turn the valve handle counterclockwise until it stops. (B) Use the water from the ActiveClean Port for cleaning surfaces such as countertops, bathrooms and hard floors. Great for using with carpet cleaning equipment such as shampoos or extractors.




CAUTION:

- Water treated by your LaundryPure 2.0 unit is NOT approved for any internal consumption such as drinking, bathing, brushing teeth, etc.
- **DO NOT** drink, ingest, or internally consume the water from your LaundryPure unit or washing machine
- **DO NOT** provide water from your LaundryPure to your pets or other animals


1. Shut off water at the cold water faucet going to the LaundryPure unit.
2. Turn the washing machine ON to relieve pressure from the hoses.
3. Remove the Power Adapter from the wall outlet and set aside.
4. Remove the the Outlet Hose from the LaundryPure 2.0.
5. Hand thread the ActiveClean Port Coupler to the Outlet Connector on the LaundryPure 2.0. Continue until it is as tight as possible by hand. (C)
6. Finish tightening by using adjustable pliers (Only tighten the Top Fitting when attaching to the Outlet Connector) **DO NOT** over tighten as over tightening may damage the plastic threads of the Outlet Fitting. (C) The Valve Stem should point to the left of the LaundryPure 2.0. The Valve Handle should be in the closed position (pointing towards you). (B)
7. Remove the adhesive backing from the included Velcro® strap and place on the bottom of the LaundryPure 2.0 in a convenient location. (D)
8. Coil the Tubing and secure it using the Velcro® strap. (E)
9. Connect the washing machine hose to the ActiveClean Port connection. Hand tighten until snug. While holding the ActiveClean Port bottom fitting with adjustable pliers, finish tightening the hose with the adjustable pliers. (E)
NOTE: If your washing machine requires water to flow through both the HOT and COLD valves for proper operation, install a "Y" adapter to the ActiveClean Port. Please see page 12 of your LaundryPure 2.0 owner's manual.
10. Ensure the ActiveClean Port is in the closed position. (B)
11. Plug the Power Cord into the electrical outlet.
12. Turn on the Cold Water Valve and check for leaks. Tighten the fittings as necessary to stop leaks, if found.




A.



B.



C.



D.



E.